


# KESÄN ODOTUS


Conditioner:

Cleaner:


## Zone Configuration



Cleaner Stop



- Zone 1
- Zone 2
- Zone 3
- Zone 4
- Zone 5



Volume: 18.48

Mode: Clean and Condition

Speed: Heavy Clean

Start Cleaner Spray: 0 Feet

Start Squeegee: 0 Feet

Start Conditioning: 6 Inches

Split Pattern: No

Zone	Ava	Ratio
Zone 1	Left	25.20 3.17 : 1
	Right	16.40 4.88 : 1
	Center	80.00
Zone 2	Left	19.20 3.23 : 1
	Right	15.40 4.03 : 1
	Center	52.00
Zone 3	Left	16.40 2.80 : 1
	Right	12.00 3.83 : 1
	Center	46.00
Zone 4	Left	11.60 3.19 : 1
	Right	10.00 3.70 : 1
	Center	37.00
Zone 5	Left	0.00 1.00 : 1
	Right	0.00 1.00 : 1
	Center	0.00

## Volume by Board

